TOYOTA AE86-F Installation instruction 1.Please remove SPINDLES from original shock P.1 WELDING