

BMW E-30-F

Installation instruction

1. Please remove SPINDLES from original shock

